

INSTALLATION INSTRUCTIONS

DRAG SPECIALTIES SOLO SEATS FOR 2000-UP SOFTAIL®

ATTENTION INSTALLER (if other than owner): Please forward this instruction sheet to the purchaser of this product. These instructions contain valuable information necessary to the end user.

INTRODUCTION: These instructions describe the procedure for properly installing Drag Specialties seats onto Softail models.

Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle and/or accessories.

WARNING!: A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.



NOTE: For 2000-2007 Deuce, the rear fender must be drilled. No kit included.

MOUNTING HARDWARE

490048 Blind Nut Kit	1
*490015A Bracket	1
*424130 Screw	2

*= Mounted on seat

NOTE: The blind nut kit has been provided for installation on certain models. In some cases, the kit will not be used. If using this kit, make sure instructions are followed closely.

PROCEDURE:

1. Begin by placing the bike on the side stand.
2. Remove the stock seat from the bike.
3. The rear bracket comes installed on seat.
4. Slip your new seat over the tab at the front of the frame near the gas tank, and position on the rear fender.
5. Center rear of seat in relation to the fender.
6. With seat centered, position rear bracket to line up with hole in fender. Remove seat and tighten the fasteners holding the bracket.
7. Slip the seat onto the front frame tab and attach the rear bracket to the fender.

FXST™ is a registered trademark of Harley-Davidson Motor Company, Inc., Milwaukee, WI, USA.

DRAG SPECIALTIES

3501 Kennedy Rd, PO Box 5222, Janesville, WI 53547-5222
P/N 010011